



**ARMREST A**





**ARMREST B**



strona/page/Seite 3

**A1**



No 119



strona/page/Seite 3

**B1**



No 47




strona/page/Seite 4

**C1**


No 104




**D1**




**E1**




**F1**





**G1**



**H1**



1




WWI M8x20


A x16

ARMREST B

A1



2



ARMREST B

B1

4x




M8x25

C x8



8,5x22

D x8



3

3



M8x25

C x4





8,5x22

D x4



φ30x3

E x8



4





φ30x3

E x4




φ45x3

F x4














4

5




6







8





3XL SEATER (two parts)




D1 E1  
G1 H1


9




10




11



**B1** No 47    **G1** No 47B




12



**C1** No 104    **G1**




13




**D1** No 153    **D1** No 153



14





**E1** No 195    **E1** No 195














15










16


ARMREST A



17

ARMREST B





Zachowaj instrukcję / Please keep instructions / Bewahren Sie die Anleitung / Merci de garder l'instruction